

<u>MODELS</u>	LCxxP50E	LCxxP70E	LCxxGA7E	LCxxGD7E
	LCXXGA8E	LCXXGD8E	LCXXBT8E	LCXXGA9E
	LCXXGD9E	LCXXSA1E	LCXXSD1E	LCXXXD1E
	LCXXXD10E	LCXXRD2E	LCXXGE1E	

PROBLEM Some modern HDMI devices are displaying no picture and no sound when connected to the TV via HDMI.

CAUSE Upon investigate it has been found that 2 possible issues can cause this problem:

1. Supplied HDMI cable – HDMI cables have been pinned out and discovered that they are not fully wired and / or wired incorrectly
2. The device is not backwards compatible with the HDMI specification

SOLUTION

1. Try a different and known working HDMI cable
2. Add a HDMI device in the middle of the connection that outputs a fully compatible HDMI signal.
Example 1 – A home cinema amplifier
Example 2 – A HDMI splitter such as <http://www.lindy.co.uk/2-port-hdmi-splitter/38026.html>